







ACANTHITE




Installation Instructions







2. Before beginning installation, turn off electrical power at the main fuse box or circuit panel.




3. Install the wall plate to the wall by screws.



4. Link power main line





- 6. Turn the power back on at the main fuse box circuit panel you disabled before installation.
- 7. Turn on the light.





WARNING:

- The safety of this fixture is guaranteed only if you comply with these instructions.
- The appliance must not be tampered with or transformed and it must be installed and used as supplied and in compliance with the national rules on installations.
- Switch-off the power supply before carrying out any maintenance operations. hot plugin is not allow and may cause damage to the luminaire.
- Installation and service must be performed by qualified service personnel.
- Any non-compliant installations will invalidate all forms of guarantee.